



STAGE 回路

特GL	No	4	3
	DMX	208	207
	CH		

2	1	No	特GL
206	205	DMX	
		CH	

下LH	No	1	2	3	4	5	6	7	8
	DMX	385	386	387	388	389	390	391	392
	CH								

8	7	6	5	4	3	2	1	No	上LH
384	383	382	381	380	379	378	377	DMX	
								CH	

下奥 60A	No	62
	DMX	476
	CH	

FC奥	No	8	7	6	5
	DMX	448	447	446	445
	CH				

4	3	2	1	No	FC奥
444	443	442	441	DMX	
				CH	

62	No	上奥 60A
474	DMX	
	CH	

下GL	
No	12
DMX	204
CH	
No	11
DMX	203
CH	
No	10
DMX	202
CH	
No	9
DMX	201
CH	

※3SLへ切替可

3SL下	
No	4
DMX	180
CH	
No	3
DMX	179
CH	
No	2
DMX	178
CH	
No	1
DMX	177
CH	

FC下	
No	16
DMX	440
CH	
No	15
DMX	439
CH	
No	14
DMX	438
CH	
No	13
DMX	437
CH	
No	12
DMX	436
CH	
No	11
DMX	435
CH	
No	10
DMX	434
CH	
No	9
DMX	433
CH	
No	8
DMX	432
CH	
No	7
DMX	431
CH	
No	6
DMX	430
CH	
No	5
DMX	429
CH	
No	4
DMX	428
CH	
No	3
DMX	427
CH	
No	2
DMX	426
CH	
No	1
DMX	425
CH	

FC上	
16	No
424	DMX
	CH
15	No
423	DMX
	CH
14	No
422	DMX
	CH
13	No
421	DMX
	CH
12	No
420	DMX
	CH
11	No
419	DMX
	CH
10	No
418	DMX
	CH
9	No
417	DMX
	CH
8	No
416	DMX
	CH
7	No
415	DMX
	CH
6	No
414	DMX
	CH
5	No
413	DMX
	CH
4	No
412	DMX
	CH
3	No
411	DMX
	CH
2	No
410	DMX
	CH
1	No
409	DMX
	CH

3SL上	
4	No
176	DMX
	CH
3	No
175	DMX
	CH
2	No
174	DMX
	CH
1	No
173	DMX
	CH

上GL	
12	No
192	DMX
	CH
11	No
191	DMX
	CH
10	No
190	DMX
	CH
9	No
189	DMX
	CH

※3SLへ切替可

下GL	
No	8
DMX	200
CH	
No	7
DMX	199
CH	
No	6
DMX	198
CH	
No	5
DMX	197
CH	

※2SLへ切替可

2SL下	
No	4
DMX	172
CH	
No	3
DMX	171
CH	
No	2
DMX	170
CH	
No	1
DMX	169
CH	

FC上	
16	No
424	DMX
	CH
15	No
423	DMX
	CH
14	No
422	DMX
	CH
13	No
421	DMX
	CH
12	No
420	DMX
	CH
11	No
419	DMX
	CH
10	No
418	DMX
	CH
9	No
417	DMX
	CH
8	No
416	DMX
	CH
7	No
415	DMX
	CH
6	No
414	DMX
	CH
5	No
413	DMX
	CH
4	No
412	DMX
	CH
3	No
411	DMX
	CH
2	No
410	DMX
	CH
1	No
409	DMX
	CH

2SL上	
4	No
168	DMX
	CH
3	No
167	DMX
	CH
2	No
166	DMX
	CH
1	No
165	DMX
	CH

上GL	
8	No
188	DMX
	CH
7	No
187	DMX
	CH
6	No
186	DMX
	CH
5	No
185	DMX
	CH

※2SLへ切替可

下GL	
No	4
DMX	196
CH	
No	3
DMX	195
CH	
No	2
DMX	194
CH	
No	1
DMX	193
CH	

※1SLへ切替可

1SL下	
No	4
DMX	164
CH	
No	3
DMX	163
CH	
No	2
DMX	162
CH	
No	1
DMX	161
CH	

FC上	
16	No
424	DMX
	CH
15	No
423	DMX
	CH
14	No
422	DMX
	CH
13	No
421	DMX
	CH
12	No
420	DMX
	CH
11	No
419	DMX
	CH
10	No
418	DMX
	CH
9	No
417	DMX
	CH
8	No
416	DMX
	CH
7	No
415	DMX
	CH
6	No
414	DMX
	CH
5	No
413	DMX
	CH
4	No
412	DMX
	CH
3	No
411	DMX
	CH
2	No
410	DMX
	CH
1	No
409	DMX
	CH

1SL上	
4	No
160	DMX
	CH
3	No
159	DMX
	CH
2	No
158	DMX
	CH
1	No
157	DMX
	CH

上GL	
4	No
184	DMX
	CH
3	No
183	DMX
	CH
2	No
182	DMX
	CH
1	No
181	DMX
	CH

※1SLへ切替可

※青枠分のフロアコンセントは下前特電盤(SB2)にハラで集中コンセント有り

F	No	3	2	1	※上下 コンモ
	DMX	459	458	457	
	CH				

※赤枠分のフロアコンセントは上前特電盤(SB1)にハラで集中コンセント有り

下前 60A	No	61
	DMX	475
	CH	

FC前	No	8	7	6	5
	DMX	408	407	406	405
	CH				

4	3	2	1	No	FC前
404	403	402	401	DMX	
				CH	

61	No	上前 60A
473	DMX	
	CH	

客C下	No	1	2
	DMX	453	454
	CH		

花C	
No	1
DMX	460
CH	
No	2
DMX	461
CH	
No	3
DMX	462
CH	

OFC下	No	1	2
	DMX	397	398
	CH		

2	1	No	OFC上
394	393	DMX	
		CH	

2	1	No	客C上
450	449	DMX	
		CH	

客C下	No	3	4
	DMX	455	456
	CH		

OFC下	No	3	4
	DMX	399	400
	CH		

4	3	No	OFC上
396	395	DMX	
		CH	

4	3	No	客C上
452	451	DMX	
		CH	

鳥屋C	No	4	3	2	1
	DMX	468	467	466	465
	CH				

特電 ND/60A	SB3(上奥)		SB4(下奥)		SB5(中奥)		SB6(特GL)		投影室	
No	ND1	ND2	ND1	ND2	ND1	ND2	ND1	ND2	ND1	ND2
DMX	485	486	487	488	489	490	491	492	493	494
CH										



新潟市民芸術文化会館  
Nigata-city Performing Arts Center  
〒951-8132 新潟市中央区一番堀通町3-2  
TEL:025-224-5618 FAX:025-224-5626  
E-mail: shomei@ryutopia.or.jp  
http://www.ryutopia.or.jp