

# Niigata City Performing Arts Center

## Studio A

### Sound Equipmets List

3-2 Ichibanboridori-cho Chuo-ku Niigata City  
951-8132 JAPAN  
Tel.+81-25-224-5618  
Fax.+81-25-224-5626  
E-mail: onkyo@ryutopia.or.jp  
<http://www.ryutopia.or.jp>

Equipment	Type	Products	Quantity
into the rack			
Mixier Board			
	MG16/4	YAMAHA	1
Amplifier			
	WP-1200A	RAMSA	1
Playback			
CD Player	DN-C615	DENON	1
CD Recorder	RCD-W500C	SONY	1
MD Recorder	MD-02	TASCAM	1
DAT	DA30MK II	TASCAM	1
Loudspeaker			
	101MM (hanged on ceiling)	BOSE	4
	WS-A200 with stand	RAMSA	2
Amplifier			
	WP-1200A	RAMSA	1
Microphone			
Dimamic Microphone			
	SM58-LC	SHURE	3
	SM58S	SHURE	2
Condenser Microphone			
	C414B-ULS	AKG	2
	C480B comb	AKG	2
	CMS-2	SANKEN	1
	CMC-54U (for recording, hanged on ceiling)	SCHOEPS	2
Microphone Stand			
	WN-272	RAMSA	1
	MS-15	Takasago	1
	MF-22TM	Takasago	2
	MF-209	Takasago	3
	PS-42	Takasago	1
	ST-210/2B	K&M	5
	ST259B	K&M	5
	HM-96	Takasago	1